



INSTALLATION INSTRUCTIONS ENGINE SANDWICH ADAPTER KIT PART # 25783

Please read these instructions completely before starting the installation.


KIT CONTENTS

QTY. DESCRIPTION	QTY. DESCRIPTION
1 Sandwich Adapter	1 18mm Sleeve Nut (White)
1 2 3/4" O-ring	1 20mm Sleeve Nut (Black)
1 3/4-16 Sleeve Nut (Yellow)	1 22mm Sleeve Nut (Green)
	1 13/16-16 Sleeve Nut (Blue)

TOOLS NEEDED

Standard Screw Driver or 5/16" Nut Driver	11/16" Open End Wrench
Dyke Pliers	1 1/8" Socket
Torque Wrench	Teflon Tape

Diagram #1



IMPORTANT

This kit is designed to fit all vehicles with engine block oil filter landings ranging from 2 1/2" to 2 3/4", which represents 60% of all vehicles. For vehicles with 3 1/2" oil filter landings, please visit www.derale.com for alternative Sandwich Adapter Kits.

IMPORTANT

In most cases the Factory Oil Filter will work with the supplied sandwich adapter. In some applications where the frame or exhaust system interferes with the new filter depth we recommend using a shorter filter length.

See chart below for possible filter options.

THREAD SIZE	LABEL COLOR	FRAM FILTER HEIGHT	FRAM P/N	WIX FILTER HEIGHT	WIX P/N	FRAM FILTER HEIGHT	FRAM P/N	WIX FILTER HEIGHT	WIX P/N
3/4-16	YELLOW	4.92	PH3600	4.83	51516	3.34	PH3614	3.4	51348
13/16-16	BLUE/RED	4.94	PH3429	4.83	51045	3.36	Ph3506	3.4	51042
18mm x 1.5	WHITE	4.94	PH3980	4.83	51036	3.36	PH3387A	3.4	51040
20mm x 1.5	BLACK	3.47	PH7317	N/A	N/A	3.39	PH3593A	3.14	51381
22mm x 1.5	GREEN	4.94	PH3750	4.57	57026	3.98	PH2	3.43	57060

SELECTING COMPONENTS

The components supplied in this kit are for multiple applications. Some components will not be used for your specific application. To easily select the correct components for your application, follow the steps below. Then proceed to the SANDWICH ADAPTER INSTALLATION section.

1. Remove the factory oil filter from the vehicle.
2. Using a rag, clean the oil filter landing on the engine.


Selecting the Sleeve Nut

There are 5 supplied Sleeve Nuts in this kit. Only 1 Sleeve Nut will be used for your application.

Note: For reference purposes Sleeve Nuts are color coded. (See Diagram #1)

1. Using the 5 supplied Sleeve Nuts, try and screw each Sleeve Nut onto the filter nipple on the engine block until the correct size will completely thread onto the nipple. Once you have located the correct Sleeve Nut, disregard the remaining 4 Sleeve Nuts.

Diagram #2



For illustrative purposes only.
Actual part may differ.

SANDWICH ADAPTER INSTALLATION

1. Take the Sandwich Adapter and two 3/8" NPT x 1/2" Hose Barbs (Sold separately), Using Teflon Tape or suitable sealant, install the hose barb fittings onto the Sandwich Adapter.
2. Take the pre-determined Sleeve Nut. Make a note of the Colored Label on the Sleeve Nut. This will allow you to reference oil filter options if necessary.
3. Remove the Colored Label from the Sleeve Nut.
4. Apply a light coat of oil onto the O-ring(s).
5. Take the O-ring(s) and install onto the Sandwich Adapter.
6. Making sure the filter landing is clean from oil and dirt, take the Sleeve Nut, Sandwich Adapter, O-ring and install onto the engine sliding the Sleeve Nut thru the Sandwich Adapter. Turn the Sleeve Nut clockwise onto the engines filter nipple. (See Diagram #2)
7. Using a Torque Wrench, torque the Sleeve Nut to 20 ft. Lbs.

(Continues on Page 2)

ROUTING HOSES (HOSE SOLD SEPARATELY)

1. Install both ends of the hose onto the Hose Barb Fittings, forming a loop.
2. Take the looped end and route the hose to the oil cooler making sure to stay clear of sharp objects, exhaust systems, etc.
Note: All bends in hose need to have a minimum radius of 5" or the diameter of a small coffee can.
3. Cut and attach hoses to the oil cooler. Secure hoses using zip ties.

VEHICLE TESTING

1. Start the engine and quickly check all connections for leaks.
2. Turn-off the engine and check oil level.
3. Add oil as needed.

Warning: Installation of accessories should only be undertaken by those with mechanical knowledge and are familiar with working on vehicles. Always use eye protection (goggles, safety glasses or shield). Park the vehicle in a well lit area, on level ground and apply the parking brake. Only work on a cold vehicle that has been sitting overnight, failure to do so will result in severe burns and injury. Before starting the vehicle, make sure no tools or any other items are left under hood that could interfere with or be drawn into moving parts of the engine. Failure to follow instructions can lead to severe damage and personal injury.