



INSTALLATION INSTRUCTIONS REMOTE COOLER INSTALL KIT PART # 15753

KIT CONTENTS


QTY.	DESCRIPTION	QTY.	DESCRIPTION
1	Sandwich Adapter	1	13/16-16 Sleeve Nut
1	O-ring	4	1/4-20 x 1" Hex Bolts
2	1/2" NPT x 1/2" Barb Fittings	8	1/4" Washers
10ft	1/2" OEM Spec Hose	4	1/4-20 Lock Nuts
4	Hose Clamps	4	6" Zip Ties

Please read these instructions completely before beginning installation

IMPORTANT

In most cases the Factory Oil Filter will work with the supplied sandwich adapter. In some applications where the frame or exhaust system interferes with the new filter depth we recommend using a shorter filter length. See the chart below for possible filter options.

SLEEVE NUT **Diagram #1**



THREAD SIZE	FRAM FILTER HEIGHT	FRAM P/N	WIX FILTER HEIGHT	WIX P/N	FRAM FILTER HEIGHT	FRAM P/N	WIX FILTER HEIGHT	WIX P/N
13/16-16	5.25	PH13	5.17	51060	4.06	PH30	4.33	51069

COOLER LOCATION (COOLER SOLD SEPARATELY)

Cooler can be mounted anywhere space permits. When selecting the best location for your vehicle, always consider a location that will deliver the maximum airflow.

MOUNTING


1. Holding the cooler in place use a marker to identify the four mounting hole locations.
2. Using a drill and 9/32" drill bit, drill the four mounting holes in the desired location.
3. Using the 1/4-20 Bolts, Washers & Lock Nuts Included, install cooler.

SANDWICH ADAPTER INSTALLATION

The Sandwich Adapter fits between the oil filter and the engine block. Before removing the oil filter, check the clearance between the bottom of the filter and the closest vehicle obstruction. If there are none, then proceed with the installation. Otherwise, the Sandwich Adapter is 2-1/4" Thick, so you will need 2-1/2" more clearance than stock. If you determine that the stock filter will not fit, refer to the Filter Chart for alternative filter heights.

1. Remove the factory oil filter from the vehicle.
2. Take the Sandwich Adapter and the two Hose Barb Fittings provided. Using Teflon Tape or a suitable sealant, screw the Hose Barb Fittings clockwise into the Sandwich Adapter until snug. (See Diagram #2)
3. Using a wrench tighten the two Hose Barb Fittings.
4. Take the O-ring provided, apply a thin film of oil and install into the O-ring groove on the Sandwich Adapter. (See Diagram #2)
5. Making sure the engine block filter landing is clean from oil and dirt, take the Sleeve Nut, Sandwich Adapter, O-ring, and install onto engine sliding the Sleeve Nut thru the Sandwich Adapter. Turn sleeve nut clockwise onto the engines filter nipple. (See Diagram #2)
6. Using a torque wrench, torque the Sleeve Nut to 20 ft. lbs. (See Diagram #2)

Diagram #2



ROUTING HOSES

1. Using the hose and clamps provided, install both ends of the hose onto the Hose Barb Fittings, forming a loop.
2. Take the looped end and route the hose to the oil cooler making sure to stay clear of sharp objects, exhaust systems, etc.

Note: All bends in hose need to have a minimum radius of 5" or the diameter of a small coffee can.

3. Cut and attach hoses to the oil cooler using the provided hose clamps. Secure hoses using zip ties.

SYSTEM CHECK

1. Before starting the vehicle, check engine oil level and add accordingly.
2. Always check fluid levels on a flat surface.
3. After installation and vehicle has completely warmed up, recheck fluid level and inspect all connections for leaks.

Warning: Installation of accessories should only be undertaken by those with mechanical knowledge and are familiar with working on vehicles. Always use eye protection (goggles, safety glasses or shield). Park the vehicle in a well lit area, on level ground and apply the parking brake. Only work on a cold vehicle that has been sitting overnight, failure to do so will result in severe burns and injury. Before starting the vehicle, make sure no tools or any other items are left under hood that could interfere with or be drawn into moving parts of the engine. Failure to follow instructions can lead to severe damage and personal injury.